

# Instructions for applying Solucote

- 1) Using 2" masking tape, tape off the area where Solucote will be applied. (I generally try to mask off an area that is about  $\frac{3}{4}$ " wider than the spot where the base fabric is exposed.)
- 2) Using THF (TetraHydroFuran), clean the entire area that still has a top layer of Urethane to a shiny and tacky surface. (Cleaning the material is extremely important. If the surface does not get cleaned well enough the Solucote and Lexatron will not stick and you will have to start over.)
- 3) Take a 1.5" paint brush and cut the bristles down to about  $\frac{1}{4}$ " long. Rewet the entire taped off area with THF. While the area is wet, use the paint brush to apply Solucote. Apply it in a circular motion, trying to "grind" the Solucote as deep into the fibers of the fabric as possible.
- 4) Allow 24 hours for curing time.
- 5) Follow the steps for applying liquid Lexatron to rebuild the top layer of Urethane fabric.